


ENGINEERING TRANSFER MODE

Make sure the machine is powered on and in standby state. The switch light is on, and the other keys are not illuminated.



① Automatic startup settings:

Press and hold the power button  for 8 seconds to set the boot mode.

Display  for automatic startup and  for manual startup.

② Lighting mode settings:

Press and hold the timer button  for 3 seconds to set the lighting mode.

Display  corresponding to the color light mode of the three color light motherboard, and  corresponding to the monochrome light motherboard.

③ Water addition mode setting:

Press and hold the water button  for 3 seconds to set the water addition mode.

Display  for automatic water addition, display  for manual water addition.

④ Broadcast voice settings:

Press and hold the light button  for 5 seconds to set the voice mode.

Display  for Chinese broadcast,  for English broadcast, and  for Russian broadcast.

⑤ Silent mode setting:

Press and hold the mute button  on the remote control for 3 seconds to set the mute mode.

Display  for machine voice broadcast mode, display  for machine full mute mode.