

V8000 HEADLAMP

USER MANUAL

For your safety, read before operating.

MODEL: V8000 Headlamp

USB RECHARGEABLE



1 WHAT'S IN THE BOX



Headlamp x1



USB Charging Cable x1



User Manual x1

2 MODE SWITCHING



Press: ON / OFF

Short press: Cycle modes

Long press: Red light / SOS



HIGH



MEDIUM



LOW



RED



STROBE



SOS

Press the switch to move to the next mode.

3 WEARING & LIGHT ANGLE

ADJUSTABLE HEAD STRAP



Slide the strap adjusters for a secure, comfortable fit.

TILTABLE LAMP HEAD



Angle the lamp downward for the best viewing area.

4 CHARGING & BASIC USE

A. USB CHARGING



- 1 Open the rubber charging-port cover.
- 2 Connect the included USB charging cable.
- 3 Connect to a 5V USB power source.
- 4 Red indicator: charging.
Green indicator: fully charged.

B. BASIC USE

- 1 Adjust the head strap to fit comfortably.
- 2 Position the lamp at the desired angle.
- 3 Press the switch to select the needed mode.
- 4 Turn off after use to save power.

IMPORTANT: Charge fully before first use.
Do not look directly into the light.

5 SAFETY & CARE

- ⚠ Do not look directly into the beam or shine it into anyone's eyes.
- ⚠ Keep away from children, heat, flames, and metal objects.
- ⚠ Do not immerse the headlamp in water.
- ⚠ Wipe dry after rain or splashes.
- ⚠ Stop use if the product becomes hot, damaged, or leaks.
- ⚠ Store in a cool, dry place when not in use.

6 TROUBLESHOOTING

🔌	NO POWER	— Recharge the headlamp and try again.
🔌	NOT CHARGING	— Check the cable, power source, and charging port.
☀	DIM LIGHT	— Recharge fully before use.
🔧	STRAP TOO LOOSE	— Readjust the strap sliders for a snug fit.
🔄	MODE ISSUE	— Press the switch firmly and cycle through the modes.
❓	STILL NOT WORKING	— Contact Victoper Support.



Need help? service@victoper.com

Include your Amazon order number and a brief issue description.



VICTOPER SUPPORT
service@victoper.com | victoper.com



QUALITY YOU CAN TRUST
Lighting Your Way, Every Day.