

VICTOPER LED TACTICAL FLASHLIGHT USER MANUAL


For your safety, read before operating.

MODEL: VT-FLV1000-2P


2-PACK | NO BATTERIES




1 WHAT'S IN THE BOX



2 MODE SWITCHING



5 LIGHTING MODES



Half-press, or quickly click OFF/ON, to move to the next mode.

3 ADJUSTABLE FOCUS

SPOT BEAM



Pull the head outward

Narrow spot beam for longer range viewing.

FLOOD BEAM




Push the head inward

Wide flood beam for nearby areas.

4 BATTERY INSTALLATION

A. 3 x AAA BATTERIES



- 1 Unscrew the tail cap and remove the AAA Holder.
- 2 Insert 3 AAA batteries according to the polarity marks.
- 3 Place each negative (-) end against a spring.
- 4 Insert the holder into the flashlight, positive tip first.
- 5 Tighten the tail cap firmly.

B. 1 x 18650 LI-ION BATTERY



- 1 Use a compatible, undamaged 18650 battery.
- 2 Remove any shipping film or insulating wrap.
- 3 Place the battery inside the supplied battery tube.
- 4 Insert the battery positive (+) end toward the flashlight head.

USE ONE POWER OPTION ONLY

IMPORTANT: Batteries and charger are not included. Do not charge batteries inside the flashlight.

5 SAFETY & CARE

- ⚠ Do not look directly into the beam or shine it into anyone's eyes.
- ⚠ Do not mix old and new battery, brands, or battery chemistries.
- ⚠ Use only 3 AAA batteries or one compatible 18650 battery.
- ⚠ Keep batteries away from children, heat, flames, and metal objects.
- ⚠ Do not immerse the flashlight in water. Dry it after rain or splashes.
- ⚠ Stop use if the flashlight or battery becomes hot, damaged, or leaks.
- ⚠ Remove batteries before long-term storage and dispose of them properly.

6 TROUBLESHOOTING

- | | |
|---------------------|--|
| ✓ NO POWER | Check polarity and charge. Remove any battery packaging film. |
| ✓ FLICKERING | Ensure threads tighten the tail cap, and clean contacts. |
| ✓ DIM LIGHT | Replace all AAA batteries together or recharge the 18650 externally. |
| ✓ MODE CHANGES | Avoid resting on the tail switch; fully click for ON/OFF. |
| ✓ STILL NOT WORKING | Try a fresh, compatible battery, then contact Victorper Support. |

Need help? service@victoper.com

Include your Amazon order number and a brief issue description.



VICTOPER SUPPORT
service@victoper.com | victoper.com



QUALITY
YOU CAN TRUST
Lighting Your Way,
Every Day.