

### CR Touch Firmware Version for 32-bit Motherboard

| Model  | Condition 1                            | Condition 2                            | Firmware Version   |
|--|--|--|--|
| Ender-3  | 4.2.2 32-bit Motherboard Firmware      | CR Touch without Filament Sensor       | Ender-3_HW4.2.2_SW2.0.8.27_CRTOUCH   |
|  |  | CR Touch with Filament Sensor          | Ender-3_HW4.2.2_SW2.0.8.27_CRTOUCH_FILAMENT  |
|  | 4.2.7 32-bit Motherboard Firmware      | CR Touch without Filament Sensor       | Ender-3_HW4.2.7_SW2.0.8.28_CRTOUCH_standard  |
|  |  | CR Touch with Filament Sensor          | Ender-3_HW4.2.7_SW2.0.8.28_CRTOUCH_FILAMENT_standard   |
| Ender-3MAX   | 4.2.2 32-bit Motherboard Firmware      | CR Touch without Adapter Board         | Ender-3 Max - V1.0.1.6 - ALT   |
|  | 4.2.7 32-bit Motherboard Firmware      | CR Touch without Adapter Board         | Ender-3 MaxMarlin2.0.6HW4.2.7ALT   |
| Ender-3Pro   | 4.2.2 32-bit Motherboard Firmware      | CR Touch without Filament Sensor       | Ender-3pro_HW4.2.2_SW2.0.8.27_CRTOUCH  |
|  |  | CR Touch with Filament Sensor          | Ender-3PRO_HW4.2.2_SW2.0.8.27_CRTOUCH_FILAMENT   |
|  | 4.2.7 32-bit Motherboard Firmware      | CR Touch without Filament Sensor       | Ender-3Pro_HW4.2.7_SW2.0.8.28_CRTOUCH_standard   |
|  |  | CR Touch with Filament Sensor          | Ender-3Pro_HW4.2.7_SW2.0.8.28_CRTOUCH_FILAMENT_standard                                      |
| Ender-3V2  | 4.2.2 32-bit Motherboard Firmware      | CR Touch without Adapter Board         | Ender-3V2_HW4.2.2_ALT1.0.6B  |
|  | 4.2.7 32-bit Motherboard Firmware      | CR Touch without Adapter Board         | Ender-3V2_HW4.2.7_ALT1.0.6B  |
|  |  | CR Touch+Filament Sensor               | Ender-3 V2-Marlin-2.0.1-HW-4.2.7-mainboard-V1.1.2-compatible with ALT and filament detection |
| Ender-5、5S   | 4.2.2 32-bit Motherboard Firmware      | CR Touch without Adapter Board         | Ender-5- Marlin2.0.1 - V1.1.1 - ALT  |
|  | 4.2.7 32-bit Motherboard Firmware      | CR Touch without Adapter Board         | Ender-5- Marlin2.0.1 - V1.1.1 - ALT - TMC2225  |
| Ender-5Pro   | 4.2.2 32-bit Motherboard Firmware      | CR Touch without Adapter Board         | Ender-5pro-HW4.2.2_SW2.0.8.28_ALT  |
|  | 4.2.7 32-bit Motherboard Firmware      | CR Touch without Adapter Board         | Ender-5 Pro- Marlin2.0.1 - V1.1.1 - ALT  |
| CR-10  | 4.2.7 (32-bit Silent Motherboard)      | CR Touch without Adapter Board         | CR-10-Marlin2.0.1-20201207-HW-V4.2.7-SW-V1.1.1 ALT-English                                   |
| Ender-5plus  | CR Touch Firmware                      | CR Touch Firmware                      | Ender-5PlusALT_0904_V1.70.2 BL.hex   |
| Ender-6  | CR Touch Firmware                      | CR Touch Firmware                      | Ender-6-V1.0.4.9-ALT   |
| Ender-7  | CR Touch Firmware+Touchscreen Firmware | CR Touch Firmware+Touchscreen Firmware | Ender7_HW-2.4.S1.101_SW-1.0.3T-ALT<br>DWIN_SET   |
| <b>Note: Creality will launch the newest firmware version on <a href="http://www.creality.com/download">www.creality.com/download</a>. Please download the corresponding firmware on official website.</b> |  |  |  |