



Email: service.us@2nice.com Live chat: www.2nice.com



www.2nice.com

**How to Connect to Alexa** 

Note: Support 2.4GHz Wi-Fi Only.



@2nice.smarthome

Facebook

@2nice.smarthome

# **Use Your Freebot WT10 With Gosund App**

To enjoy all available features, it is recommended to control your WT10 via the Gosund App.

#### Download and Install App

#### Option 1:

Scan the QR code, download and install the App



## **APP Registration and login**

Launch Gosund APP, register an account with your mobile phone number or a valid email address at your first use, then log in.

Note: For a successful connection, please allow Gosund APP to use your WLAN & Cellular Data when running it.

### Option 2:

Search for "Gosund", download and install.







IOS 9.0 or later Android 4.0 or later

### Before You Start, Make Sure That


#### For Your Robot:

Make sure the robot has enough power and the Power Switch of the robot is pressed to ON.

#### For WiFi Network:

- Make sure your mobile device is connected to a 2.4GHz WiFi(5G WiFi is not acceptable). If your router is a dual-band router, please select the 2.4GHz network.
- Make sure you've entered the correct WiFi name and password when connecting.
- Avoid using an emoji or special characters or symbols in your WiFi name and password.
- It's not recommended to use a VPN(Virtual Private Network) or Proxy Server.
- Make sure the robot and your mobile device are close to the touter when connecting.

#### Add The Robot To The App




- Tap Add Device
- Select Home Appliance Tap Robot Vacuum
- Follow the steps in the app to complete the setting

- After connecting successfully, you can control the robot via the app. - With the app, you can select a cleaning mode, set the time, schedule a cleaning, view the battery status and access additional features.


**How to Connect to Alexa** Note: Support 2.4GHz Wi-Fi Only.

1. Make sure your Alexa device is powered on and connected to a Wi-Fi network.


2. Open Amazon Alexa APP and select "skills & Games," as shown in the figure below.




3. Click "Search" icon and enter" Gosund", as shown in the following figure.




4. Find "Gosund", click "enable" and contact your Gosund account to enable skill. As



shown in the figure below:




+86 ▼ Phone Number/Email Address



Done **a gosund.tuyaus.com** AA ♂ The following Apps all support skill. Please select an App to log in


controlled through Alexa. Link Account X 

5. Then the device can be



and login in.

2. Tap your account name of the upper right corner.



Assignable reminders
Choose who can send you reminders

4. Find "Link a smart home device" and click it.



**How to Connect Gosund Devices to Google Assistant** 

Note: Support 2.4GHz Wi-Fi Only.

5. Enter "Gosund" to search and click the "Gosund smart".

6. Enter your Gosund APP account and password,then tap "Link Now".

7. Now you can begin your smart home journey.




料 号 扫地机器人WT10-配网指引(英文版) 128g哑粉纸,单黑双面印刷+1专 材质工艺 210x148mm (4折页)

Pantone: 1655C

**How to Connect Gosund Devices to Google Assistant** Note: Support 2.4GHz Wi-Fi Only.

1. Open the Google Assistant APP 3. Click "Devices" to add devices.



Gosund smart