


# Mechanical Keyboard

# M87K-SW

87Key Hot Swap Type-C Full RGB



## User Manual

Please read the instructions carefully before using this product and keep it well for referen.

## Basic Specification

Device Type: Mechanical Keyboard

Model No.: M87K-SW

Cable Length: 150CM

Interface Port: USB to Type-C

Operation System: Win7/8/10, MAC OS

## Function Key Description

- FN** + **F1** = Player
- FN** + **F2** = Volume down
- FN** + **F3** = Volume up
- FN** + **F4** = Mute
- FN** + **F5** = Stop
- FN** + **F6** = Previous song
- FN** + **F7** = Play/Pause
- FN** + **F8** = Next song
- FN** + **F9** = Email
- FN** + **F10** = Home page
- FN** + **F11** = Calculator
- FN** + **F12** = Macro recording
- FN** + **ESC** = Reset

## Macro Recording

**Function Key:** FN+F12

Recordable Marco Keys: Y\U\I\O\P

Marco Key: FN+Y

FN + F12 after entering the marco recording funtion, the five macro definition keys Y\U\I\O\P flash, at this time, select any group to enter the recording of each group.

Only 32 keys can be recorded, after recording, press FN+F12 to save the recording and exit.

# After entering the recording, it is detected that no buttions are pressed in 10S automatically save and exit.

After FN+Y is enabled, the five keys Y\U\I\O\P are always on in white, at this time, press the macro key to be played.

(Pressing the marco key that has not been recorded will be the original key value of the playback key), And press FN+Y again to turn off the macro enable.

## RGB Backlit Control

- FN** + **PRO** = Full color lighting
- FN** + **SCN** = Foreground color
- FN** + **BCN** = Background color
- FN** + **LDN** = Light direction
- FN** + **BLN** = Light brightness
- FN** + **LSN** = Light speed
- FN** + **RGB** = Full Light Modes
- FN** + **DEL** = Interactive lighting mode

The flashing function indicates three times when reaching the highest or lowest for the light brightness and speed.

## Backlit Effects

- Wave mode (default)**  
\* Wave mode has 6 directions: left, right, up, down, gather and diffusion.
- Breathing mode**
- Neon mode**
- Starry mode**
- Horse racing mode**  
\* Horse racing mode has 2 directions: left and right.
- Radar mode**  
\* Radar mode has 2 directions: clockwise and counterclockwise
- Ripple mode**  
\* Ripple mode has 2 directions: gather and diffusion.
- Single light mode**
- Always on mode**
- Cross mode**
- Response mode**  
\* Response mode has 2 directions: up and down.
- Aurora mode**  
\* Aurora mode has 2 directions: gather and diffusion.

## Light Recording

**Function Key:** FN+END

- FN** + **RGB** = W\A\S\D\↔\↵\↑\↓
- FN** + **RGB** = Q\W\E\R\T\Y\U\I\O\P\↵\A\S\D\F\G\H\J\K\L\↵\Z\X\C\V\B\N\M\,\/?

When you press FN + END, the two buttons PGUP\PGDN will flash. At this time, select any one of them for recording.

Press again to display red -orange -yellow -green -cyan -blue -purple -white -off, after confirming the color to be recorded, press FN+END again to save.

# After entering the recording, it is detected that no buttions are pressed in 10S, automatically save and exit.

# Mechanical Keyboard

# M87K-SW